



# TRI-CHEM

## WHITE ELASTOMERIC ROOF CEMENT

### Durable Roof Cement

#### DESCRIPTION

White Elastomeric Roof Cement is processed with a special resin, titanium dioxide white pigment and special reinforcing fibers to make it a resilient, long lasting and durable patch which provides premium protection to withstand the sun's rays and resist mildew and weathering.

#### FEATURES

- Repairs metal, polyurethane foam and masonry
- Provides highly flexible, watertight seal over seams, fasteners, around protrusions, skylights, vents, flashings around mounted equipment and any other suspected leak areas
- Ready to use from the container – requires little or no mixing
- May be applied over damp, not wet, surfaces

#### HMSI SYMBOL

Health	1
Fire	0
Reactivity	0
Personal Protection	

#### FIRST-AID

**Eyes:** Remove contact lenses and flush eyes with large amounts of luke warm water for at least 15 minutes. Do not rub or scratch eyes. If symptoms occur, seek medical attention.

**Skin:** Wash with soap and large amounts of luke warm water. Remove contaminated clothing and shoes and wash before reuse. If symptoms occur, seek medical attention.

**Inhalation:** Remove victim to fresh air. If difficulty breathing trained personnel should give CPR and/or administer oxygen as needed. Immediately seek medical attention.

**Ingestion:** Do NOT induce vomiting and do NOT give liquids. Rinse mouth with water to remove material from throat. Seek medical attention immediately.

#### CAUTION

Please refer to the SDS for more detailed precautionary measures, handling instructions, and emergency procedures.  
**KEEP OUT OF REACH OF CHILDREN.**

#### DIRECTIONS

- Surface must be power washed at a minimum of 2,000 psi to remove all dirt, loose paint, dried out caulk and other foreign matter which could prevent proper adhesion.
- Apply with a brush, trowel or putty knife.
- To repair cracks and seams, remove all dried out and loosely adhered caulking and coating.
- Apply cement over entire length of seam or crack; apply 1 - 2" wider than the polyester fabric.
- Embed fabric into cement, smoothing fabric carefully without stretching.
- Apply second layer of cement, completely covering fabric and ensuring that all edges and corners of fabric are firmly embedded.
- Not for use on wood.
- Do not apply when temperature is below 50° F or when rain is forecast.
- High humidity will extend dry time
- Allow cement to dry a minimum of 4 hours before exposure to rain, heavy dew or temperatures below 50°F.
- Protect from freezing.